

# **Apprentice & Journeymen Training Trust Fund**

## **Of the Southern California Plumbing & Piping Industry**

### **Eye and Face Protection Policy & Procedure**

1. ANZI Z87 rated safety glasses with side shields must be worn in shops at all times.
2. Goggles with hooded ventilation must be worn, in addition to face shields, for all tasks involving, but not limited to:
  - Overhead drilling and chipping operations.
  - Overhead PVC priming and gluing.
  - Using, mixing, dispensing or transferring hazardous liquids.
3. Face shields must be worn on top of safety glasses or goggles for tasks involving, but not limited to:
  - Splashes from hazardous liquids.
  - Flying particles while chiseling, chipping, cutting or grinding.
4. Welding hood must be worn on top of safety glasses or goggles, and hood must be equipped with a filter lens appropriate for the welding operations.
5. Shaded face shield or shaded safety glasses (refer to Figure 1-1 P.P.E. Shale Level Selection Chart) must be worn for all torch work, such as:
  - Brazing.
  - Cutting.
  - Welding.